Insulation fault locators EDS460/490 - EDS461/491

Insulation fault locators with control and display function for insulation fault location systems



Insulation fault locator EDS460-L

Device features

- Insulation fault location in IT systems
- · For AC, 3AC, DC and IT systems
- · Control and display function in a single device (EDS...-D)
- 12 measuring channels (circuits) for measuring current transformers of the W, WR, WS series
- Up to 90 EDS insulation fault locators in the system (1080 measuring channels)
- · Scanning time max. 10 s for all measuring channels (parallel scanning)
- · Response sensitivity EDS460/490 2...10 mA EDS461/491 0,2...1 mA
- · History memory to store 300 events
- · Two alarm relays with one changeover contact each
- N/O or N/C operation, selectable
- · Connection external test/reset button
- · Indication via graphical display resp. 7-segment display and alarm LEDs
- BMS address range 1...90
- Serial interface RS-485
- · Continuous CT connection monitoring
- · Fault memory behaviour selectable
- Device version EDS490/491 with one alarm contactor per channel
- · Additional AC residual current measurement

Standards, approvals and certifications











Product description

The insulation fault locators EDS460/490 in combination with the A-ISOMETER® IRDH575 or the locating current injector PGH are applied for localising insulation faults in unearthed systems (IT systems). The locating current signals generated by the insulation monitoring device IRDH575 or the locating current injector PGH are detected by measuring current transformers and evaluated by the insulation fault locators. Up to 12 measuring current transformers can be connected to one EDS460 / 490. A total of 90 EDS insulation fault locators can be connected via one RS-485 interface (BMS protocol). Hence, up to 1080 circuits can be monitored. The maximum scanning time is ...10 s, see TGH1394.

Application

- Insulation fault location in AC, AC / DC and DC IT systems
- · Main and control circuits in industrial installations and ships
- Diode-decoupled DC IT systems in power stations
- · Systems for medical locations

Function

Insulation fault location is started manually or automatically via the A-ISOMETER® IRDH575 or the PGH. Once started, the insulation fault locator EDS simultaneously scans all measuring current transformers (channels). If several EDS exist, these devices are also scanned simultaneously.

When the locating current detected by a measuring current transformer exceeds the set response value, the alarm LED 2 lights up, the common alarm relay switches and the faulty circuit is indicated as plain text on the graphical display. Version EDS...L indicates faulty outgoing circuits via alarm LEDs. The connection between the measuring current transformer and the insulation fault locator is continuously monitored. In the event of wire interruption, the alarm LED 1 lights up and the alarm relay switches.

With the fault memory activated, the alarm messages of the individual channels remains stored until the reset button is pressed or until a reset command is given via the RS-485 interface. When the fault memory is deactivated, the alarm message remains stored until the insulation fault is eliminated.

History memory in EDS460/461-D/EDS490/491-D

The device utilises a history memory for failsafe storing of up to 300 measured values/ events (date, time, channel, event code, measured value), so that all data about an outgoing circuit or an area can be traced back at any time (what happend when).

AC residual current measurement

EDS insulation fault locators can also be used for the indication of AC residual currents in unearthed power supplies (IT systems). This is essential when also AC residual currents are to be localised in the circuits.

Device variants

EDS460-D

Device version EDS460-DG features a backlit graphical display where information can be displayed in various ways. This version is applied when detailed information about all devices in the switchboard cabinet, connected to the bus, are to be displayed locally. This device is capable of assigning parameters to all devices connected to the BMS bus and displaying all measurement details. Several EDS460-DG devices can be used in one system.

FDS460-L

Device version EDS490D/EDS490L utilises a two-digit 7-segment display where the address of this device is displayed within the BMS bus. Various error codes are displayed too. The alarm LEDs indicate in which measuring channel the response value has been exceeded. Parameter setting is only possible via an EDS...D, an A-ISOMETER® IRDH575, the alarm and test combination MK2430 or the protocol converter FTC470XET.

EDS490-D/EDS490-L

In comparison to the device version described before, EDS490-D / EDS490-L feature a galvanically isolated alarm contact (N/O contact), for example, to trigger a circuit breaker in this subcircuit when a response value has been exceeded.



EDS461-D/-L and EDS491-D/-L

In comparison to the device versions described above, these versions provide a higher response sensitivity. They are preferrably used in control circuits or in medical locations up to AC 230 (DC 220) V.


Standards

The device was designed according to the following standards: IEC 61557-8, IEC 61326-2-4, IEC 60664-1, IEC 60664-3, IEC 61557-9, ASTM F1669M-96 (2007), ASTM F1207M-96 (2007).

Overview of device types

| Distinctive device features | | EDS460-D/EDS461-D | EDS460-L/EDS461 -L | EDS490-D/EDS491 -D | EDS490-L/EDS491 -L | |
|---|----------|--------------------------|--------------------------|--------------------------|--------------------------|--|
| Response value | | EDS460: 2 | 10 mA | EDS490: 2 | 210 mA | |
| | | EDS461: 0 | .21 mA | EDS491: 0 | .21 mA | |
| Residual current indication | | EDS460: 100 | mA10 A | EDS490: 10 | EDS490: 100 mA10 A | |
| | | EDS461: 10 |) mA1 A | EDS491: 10 |) mA1 A | |
| Backlit graphics LC display | | × | | × | - | |
| 7-segment display and LED line | | | × | | × | |
| Parameter setting function | | × | | × | - | |
| Error code indication | | × | | | × | |
| Address range | | 190 | 190 | 190 | 190 | |
| Internal clock | • | × | | X | | |
| History memory | | × | | × | - | |
| Alarm contact "Common alarm" for all channels | | 2 x 1 changeover contact | |
| Alarm contact per channel | | | | 12 x 1 N/ | O contact | |
| Enclosure | | XM | 460 | XM | 490 | |
| | | | | | | |

Wiring diagram - Operating elements EDS46...-D/-L und EDS49...-D/-L



- 1 LED "ALARM 1" lights up in case of the following system faults:
 - when the residual current exceeds > 10 A (EDS460/490) or > 1 A (EDS461/EDS491) (RCM function)
 - when there is a loss of power or short circuit in a measuring current transformer circuit (this function can be deactivated)
- 2 LED "ALARM 2" lights up when an insulation fault is detected on a channel (EDS function)
- 3 Power On LED "ON"
- 4 LC graphical display
- 5 "INFO" button: to query standard information (does not apply to EDS...L).ESC button: back to menu function.


- **6** "TEST" button: to call up the self test. Arrow up button: parameter change, scroll
- 7 "RESET" button: to acknowledge insulation and fault messages Arrow down button: parameter change, scroll
- 8 "MENU" button: EDS...-D: to toggle between the standard display, menu and alarm indication EDS...-L: to set the BMS address

Enter button: to confirm parameter change


- 9 Alarm LEDs "1...12", light up if an insulation fault has been detected in the relevant channel.
- 10 Digital indication for device address and error codes (parameter setting (EDS460/490-D only).



Wiring diagram - Mains connection EDS460/461-D/-L and EDS490/491-D/-L




- 1 Supply voltage U_S , see ordering information, 6 A fuse recommended. Two fuses are required for IT systems.
- 2 Connection measuring current transformers k1...k12
- 3 Serial interface RS-485
- 4 External reset button "R/T" (N/O contact)*
- 5 External test button "R/T" (N/O contact)*




- 6 Alarm relay 1
- 7 Alarm relay 2
- 8 Alarm relay: one N/O contact per channel (EDS490/491 only)
- **9** " $R_{\text{on/off}}$ ": Termination of the serial RS-485 interface (A/B) with 120 Ω
- * The external test/reset buttons of several devices must not be connected to one another.



Example for system set-up



Example for system set-up



Note:

The DI-1 repeater only is required when the length of the cable exceeds 1200 m or when more than 32 devices are connected to the bus.



Technical data

| Technical data | |
|--|--|
| Insulation coordination acc. to IEC 60664-1 / IEC 60664-3 | Time response |
| for versions with a supply voltage of AC/DC 70276 V AC 42460 Hz | Response delay t_{on} 024 s |
| Rated insulation voltage AC 250 V | |
| Rated impulse voltage/pollution degree 6 kV / II | · · · · · · · · · · · · · · · · · · · |
| Protective separation (reinforced insulation) between (A1, A2) - (k1, 1k12, R, T/R, T, A, B) | |
| C11, C12 C14), (C21, C22, C24), (11,14), (21,24), (31,34), (41,44), (51,54) | |
| 61,64), (71,74), (81,84), (91,94), (101,104), (111,114), (121,124 | |
| Protective separation (reinforced insulation) between (C11, C12, C14) - (C21, C22, C24) - (C11, C12, C14) - (C21, C22, C24) - (C11, C12, C14) - (C11, C12, C | 011/414014/ |
| (11, 14, 21, 24, 31, 34) - (41, 44, 51, 54, 61, 64) - (71,74) | |
| (81,84) - (91,94) - (101,104) - (111,114) - (121,124) | 7 |
| Voltage test acc. to IEC 61010-1 3.536 kV Rated insulation voltage AC 250 V | |
| Rated insulation voltage Rated impulse voltage/pollution degree 4 kV / II | |
| Basic insulation between: k1, 1k12, R, T/R, T, A, B) - (C11, C12, C14), (C21, C22, C24 | |
| Basic insulation between: (11, 14) - (21, 24) - (31, 34) - (41, 44) - (51, 54) - (61, 64 | |
| Voltage test acc. to IEC 61010-1 2.21 kV | · · · · · · · · · · · · · · · · · · · |
| | inputs/outputs |
| Insulation coordination acc. to IEC 60664-1 / IEC 60664-3 | Test / reset button internal/external |
| for versions with a supply voltage of DC 1694 V, AC 42460 Hz 1672 V | Cable length for external test/reset button 010 m |
| Rated insulation voltage AC 100 V | IIILEITALE |
| Rated impulse voltage/pollution degree 2.5 kV / II | · Interface/protecti |
| Protective separation (reinforced insulation) between (A1, A2) - (k1, Ik12, R, T/R, T, A, B | Raudinto 0.6 khit / c |
| Voltage test acc. to IEC 61010-1 1.344 kV | Cable langth 0 1200 mg |
| Rated insulation voltage AC 250 V | Paramondad cable (abidad abida arandada DT aranda) min LV(Ct)V 2v0.0 |
| Rated impulse voltage/pollution degree 4 kV / II | Townshotter verifical |
| Basic insulation between (A1, A2), (k1, Ik12, R, T/R, T, A, B) | Davisa address PMS hus |
| (C11, C12, C14), (C21, C22, C24), (11,14), (21,24), (31,34), (41,44), (51,54) | |
| (61,64), (71,74), (81,84), (91,94), (101,104), (111,114), (121,124 | |
| Basic insulation between: (11, 14) - (21, 24) - (31, 34) - (41, 44) - (51, 54) - (61, 64) | |
| Voltage test acc. to IEC 61010-1 2.21 kV Rated insulation voltage AC 250 V | Single wire, twisted \geq 0.75 mm ⁻¹ 110 m |
| Rated insulation voltage Rated impulse voltage/pollution degree 6 kV / II | Silielded cable ≥ 0.5 lillil |
| Protective separation (reinforced insulation) between (C11, C12, C14) - (C21, C22, C24) | keconinended cable |
| (11, 14, 21, 24, 31, 34) - (41, 44, 51, 54, 61, 64) - (71,74) | (Shielded Shield on one side connected to i-conductor) not connected to earth) |
| (81,84) - (91,94) - (101,104) - (111,114) - (121,124) | |
| Voltage test acc. to IEC 61010-1 3.536 kV | |
| - | 2 relays with one changeover contact each , 12 relays with one N/O contact each (EDS49.) |
| Supply voltage | Operating principle NC / N/O operation (N/O operation)* |
| Supply voltage $U_{\rm S}$ see ordering information | Electrical endurance, number of cycles 10.000 |
| Frequency range U_S AC 42460 Hz | Contact data acc. to IEC 60947-5-1 |
| Power consumption \leq 10 VA (EDS460/461 | Utilisation category AC-13 AC-14 DC-12 DC-12 DC-12 |
| ≤ 14 VA (EDS490/491 | Rated operational voltage 230 V 230 V 24 V 110 V 220 V |
| Measuring circuit | Rated operational current (common alarm relays) 5 A 3 A 1 A 0.2 A 0.1 A |
| | Pated operational current (slave relea) 2A 05A 5A 02A 01A |
| Nominal system voltage U_n see IRDH575, PGH (EDS460, EDS490 AC 20276 V, DC 20308 V (EDS461, EDS491 | Minimum contact rating $1 \text{ mA} \Rightarrow M/DC > 10 \text{ V}$ |
| External measuring current transformers type W, WR, WS (EDS460, EDS490 | |
| W/8000, WS/8000 (EDS461, EDS491 | |
| CT monitoring on/off (on) ³ | EIVIC IEC 01320-2-4 |
| Load 10 Ω (EDS460/490), 1.5 kΩ (EDS461/491 | operating temperature -23 C+33 C |
| Rated insulation voltage (measuring current transformer) 800 \ | Cillidatic class acc. to lec 60721 |
| Response sensitivity 210 mA (EDS460/EDS490 | Stationary use (IEC 60721-3-3) SNS (except condensation and formation of ice) |
| 0.21 mA (EDS461/EDS491 | transport (IEC 60721-3-2) ZK3 (except condensation and formation of ICE) |
| Rated frequency DC, AC 50 / 60 / 400 Hz | Long-time storage (IEC 60721-3-1) |
| Measuring range EDS function 1,550 mA (EDS460/EDS490 | Classification of inechanical conditions IEC 00721 |
| 0.155 mA (EDS461/EDS491 | Stationary use (IEC 60721-3-3) |
| Measuring range RCM function 100 mA10 A (EDS460/EDS490 | Transport (IEC 00721-3-2) |
| 10 mA1 A (EDS461/EDS491 | LUING-LIIIC STOIGNE LIFE OUT Z 1-3-17 |
| Number of measuring channels (per device/system) 12 / 1080 | |



Connection screw-type terminals

| Connection properties: | |
|--|--|
| rigid/flexible/conductor sizes | 0.24 / 0.22.5 mm ² (AWG 2412) |
| Multi-conductor connection (2 conductors with th | e same cross section): |
| rigid/flexible | 0.21.5 / 0.21.5 mm ² |
| Stripping length | 89 mm |
| Tightening torque | 0.50.6 Nm |
| Other | |
| Operating mode | continuous operation |
| Position of normal use | any |
| Degree of protection, terminals (IEC 60529) | IP20 |
| Enclosure material | polycarbonate |
| Flammability class | UL94 V-0 |
| Screw mounting | 2 x M4 |
| DIN rail mounting acc. to | IEC 60715 |
| Weight | < 360 g (EDS460) |
| | < 530 g (EDS490) |

^{()*} factory setting



| Ordering information | | | | |
|----------------------|--------------------------------|----------------|-------------|--|
| Туре | Supply voltage <i>U</i> s* | Response value | Art. No. | |
| EDS460-D-1 | AC 42460 Hz 1672 V / DC 1694 V | 210 mA | B 9108 0001 | |
| EDS460-D-2 | AC/DC 70276 V, AC 42460 Hz | 210 mA | B 9108 0002 | |
| EDS460-L-1 | AC 42460 Hz 1672 V / DC 1694 V | 210 mA | B 9108 0003 | |
| EDS460-L-2 | AC/DC 70276 V, AC 42460 Hz | 210 mA | B 9108 0004 | |
| EDS461-D-1 | AC 42460 Hz 1672 V / DC 1694 V | 0.21 mA | B 9108 0005 | |
| EDS461-D-2 | AC/DC 70276 V, AC 425460 Hz | 0.21 mA | B 9108 0006 | |
| EDS461-L-1 | AC 42460 Hz 1672 V / DC 1694 V | 0.21 mA | B 9108 0007 | |
| EDS461-L-2 | AC/DC 70276 V, AC 42460 Hz | 0.21 mA | B 9108 0008 | |
| EDS490-D-1 | AC 42460 Hz 1672 V / DC 1694 V | 210 mA | B 9108 0009 | |
| EDS490-D-2 | AC/DC 70276 V, AC 42460 Hz | 210 mA | B 9108 0010 | |
| EDS490-L-1 | AC 42460 Hz 1672 V / DC 1694 V | 210 mA | B 9108 0011 | |
| EDS490-L-2 | AC/DC 70276 V, AC 42460 Hz | 210 mA | B 9108 0012 | |
| EDS491-D-1 | AC 42460 Hz 1672 V / DC 1694 V | 0.21 mA | B 9108 0013 | |
| EDS491-D-2 | AC/DC 70276 V, AC 42460 Hz | 0.21 mA | B 9108 0014 | |
| EDS491-L-1 | AC 42460 Hz 1672 V / DC 1694 V | 0.21 mA | B 9108 0015 | |
| EDS491-L-2 | AC/DC 70276 V, AC 42460 Hz | 0.21 mA | B 9108 0016 | |

| Accessories | | |
|--|--|-------------|
| Туре | Supply voltage <i>U</i> _S * | Art. No. |
| DI-1PSM (RS-485 interface repeater) | AC / DC 24 V ± 20 % | B 9501 2044 |
| DI-2USB (interface converter RS-485/USB) | supplied by USB interface | B 9501 2045 |
| AN471 (power supply unit for DI-1 or DI-2) | AC 230 V 50/60 Hz /AC, DC 20 V | B 924 189 |
| Snap-on mounting W20/35 | | B 9808 0501 |
| Snap-on mounting W60 | | B 9808 0502 |

| Repeaters and interface converters | | | |
|------------------------------------|----------------------------------|-------------|--|
| Туре | Supply voltage U₅* | Art. No. | |
| FTC470XDP | DC 85276 V / AC 50400 Hz 85276 V | B 9506 1000 | |
| FTC470XMB | DC 85276 V / AC 50400 Hz 85276 V | B 9506 1002 | |
| FTC470XET | DC 85276 V / AC 50400 Hz 85276 V | B 9506 1001 | |

^{*} Absolute values

| Measuring current transformers for EDS460/490 | | | | |
|---|----------------------|----------------------|-------------|--|
| Туре | Internal diameter/mm | Type of construction | Art. No. | |
| W20 | 20 | circular | B 9808 0003 | |
| W35 | 35 | circular | B 9808 0010 | |
| W60 | 60 | circular | B 9808 0018 | |
| W120 | 120 | circular | B 9808 0028 | |
| W210 | 210 | circular | B 9808 0034 | |
| WR70x175 | 70 x 175 | rectangular | B 9808 0609 | |
| WR115x305 | 115 x 305 | rectangular | B 9808 0610 | |
| WS20x30 | 20 x 30 | split-core type | B 9808 0601 | |
| WS50x80 | 50 x 80 | split-core type | B 9808 0603 | |
| WS80x80 | 80 x 80 | split-core type | B 9808 0605 | |
| WS80x120 | 80 x 120 | split-core type | B 9808 0606 | |
| WS80x160 | 80 x 160 | split-core type | B 9808 0608 | |


| Alternative measuring current transformers from the Bender range | | | | |
|--|----------------------|----------------------|-----------|--|
| Туре | Internal diameter/mm | Type of construction | Art. No. | |
| W10/600 | 10 | circular | B 911 761 | |
| W0-S20 | 20 | circular | B 911 787 | |
| W1-S35 | 35 | circular | B 911 731 | |
| W2-S70 | 70 | circular | B 911 732 | |
| W3-S105 | 105 | circular | B 911 733 | |
| W4-S140 | 140 | circular | B 911 734 | |
| W5-S210 | 210 | circular | B 911 735 | |
| WR 70x175S | 70x175 | rectangular | B 911 738 | |
| WR 115x305S | 115x305 | rectangular | B 911 739 | |
| WR 150x350S | 150x350 | rectangular | B 911 740 | |
| WR 200x500S | 200x500 | rectangular | B 911 763 | |
| WS 50x80S | 50x80 | split-core type | B 911 741 | |
| WS 80x80S | 80x80 | split-core type | B 911 742 | |
| WS 80x120S | 80x120 | split-core type | B 911 743 | |
| WS 80x160S | 80x160 | split-core type | B 911 755 | |


| Measuring current transformers for EDS461/491 | | | | |
|---|---------|-----------------|-------------|--|
| Type Internal diameter/mm Type of construction Art. No. | | | | |
| W20-8000 | 20 | circular | B 9808 0009 | |
| W35-8000 | 35 | circular | B 9808 0017 | |
| W60-8000 | 60 | circular | B 9808 0027 | |
| WS20x30-8000 | 20 x 30 | split-core type | B 9808 0602 | |
| WS50x80-8000 | 50 x 80 | split-core type | B 9808 0604 | |

| Alternative measuring current transformers from the Bender range | | | |
|--|----------------------|----------------------|-----------|
| Туре | Internal diameter/mm | Type of construction | Art. No. |
| W10/8000 | 10 | circular | B 911 759 |
| W1-35/8000 | 35 | circular | B 911 756 |
| WS20x30/8000 | 20 x 30 | split-core type | B 911 764 |
| WS50x80/8000 | 50 x 80 | split-core type | B 911 757 |
| W10/8000-6 | 10 | circular, 6x | B 911 900 |



Response sensitivity in relation to the system capacitance





Explanatory notes on the response sensitivity

The value of the maximum response sensitivity decreases in relation to the system leakage capacitance. The following maximum response values can be reached:

 $30~\Omega$ / V with a system voltage of max. 20000 μFV (product of the nominal voltage and system leakage capacitance)

Example: system voltage 230 V $20000~\mu\text{FV}~/~230~V=87~\mu\text{F}$ 230 V x 30 $\Omega/\text{V}=6.9~k\Omega$ minimum response value at 87 μF system leakage capacitance

Dimension diagrams XM460 and XM490

Dimensions in mm

EDS46...-D/-L - XM460

